

ARTFORMS[™] MODULAR PANEL SYSTEM









IDEA BOOK

TABLE OF CONTENTS





















































TABLE OF CONTENTS


















BENCH & PLANTER













IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.







(PANELS & HARDWARE)


CORNER BENCH & PLANTER











IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

| REQUIRED PANELS | |
|---|--------|
| CLOSED END 18 x 36 PANEL | 8x |
| AOR B 18 x 36 PANEL | 8x |
| CLOSED END 6 x 36 PANEL | 0x |
| CORD 6 x 36 PANEL | 0x |
| IMPORTANT: 18 x 36 panels are solo pair/layer or in full pallet only. 6 x 36 pare sold per unit or in layer or in full | panels |


| REQUIRED HARDWARE | | |
|-------------------|-------------------------|------|
| | ANCHOR SLIDE AND NUT | 74x |
| 0:0:0 | JOINING PLATE | 16x |
| | OUTER CORNER | 20x |
| DA. | INNER CORNER | 0x |
| otototototot | STRETCHER | 1x |
| TOTAL WEIG | HT 2315 | l he |


(PANELS & HARDWARE)


BENCH & VERTICAL PLANTER












REQUIRED PANELS CLOSED END **4**x 11x 0x 0xIMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.





IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.


SMALL BBQ












IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.





| REQUIRED HARDWARE | | |
|-------------------|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 40x |
| | JOINING PLATE | 12x |
| | OUTER CORNER | 8x |
| | INNER CORNER | 0x |
| - interpolation | STRETCHER | 0x |
| TOTAL WEIGH | 1 4 4 4 | Lbs |


5. MEDIUM BBQ












IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.





| REQUIRED HARDWARE | | |
|-------------------|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 48x |
| | JOINING PLATE | 10x |
| | OUTER CORNER | 14x |
| | INNER CORNER | 0x |
| afanjanjanjanjanj | STRETCHER | 0x |
| TOTAL WEIGH | 1653 | Lbs |


6. LONG BBQ












IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.




| REQUIRED HARDWARE | | |
|-------------------|-------------------------|--------------------|
| 56x | ANCHOR SLIDE AND NUT | |
| 14x | JOINING PLATE | |
| 14x | OUTER CORNER | |
| 0 x | INNER CORNER | |
| 0x | STRETCHER | atestestestestest) |
| | | |


TOTAL WEIGHT 1956 Lbs


L-SHAPE BBQ












IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.





| REQUIRED HARDWARE | | |
|------------------------|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 76x |
| | JOINING PLATE | 26x |
| | OUTER CORNER | 10x |
| | INNER CORNER | 2x |
| advertised and and and | STRETCHER | 1x |
| TOTAL WEIGH | ZXAS | Lbs |


CORNER BBQ & PIZZA GRILL












IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.


| REQUIRED PANELS |
|---|
| CLOSED END 18 x 36 PANEL 10 X |
| 18 x 36 PANEL 18 X |
| CLOSED END 6 x 36 PANEL 0x |
| 6 x 36 PANEL 0x |
| IMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet. |


| REQUIRED HARDWARE | | |
|-------------------|-------------------------|------|
| | ANCHOR SLIDE AND NUT | 110x |
| | JOINING PLATE | 30x |
| | OUTER CORNER | 21x |
| | INNER CORNER | 4x |
| ristatetatetal | STRETCHER | 1x |
| TOTAL WEIGH | 49./-/ | Lbs |

CORNER BBQ & PIZZA GRILL










IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.


BBQ WITH LUXURY COUNTER & BAR




REQUIRED PANELS











18 x 36 PANEL 10x 23x 4x 5x IMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet. **REQUIRED HARDWARE** ANCHOR SLIDE AND NUT 150x 54x JOINING PLATE 22x OUTER CORNER 6x INNER CORNER 0xSTRETCHER TOTAL WEIGHT 5105 Lbs

IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.

BBQ WITH LUXURY COUNTER & BAR









IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.


COUNTER & BAR
















| REQUIRED HARDWARE | | |
|-----------------------|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 76x |
| \$ 10.20 | JOINING PLATE | 34x |
| | OUTER CORNER | 4x |
| | INNER CORNER | 0x |
| atestestestestest | STRETCHER | 0x |
| TOTAL WEIGHT 1968 Lbs | | |


LARGE COUNTER














| REQUIRED HARDWARE | | |
|-------------------|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 48x |
| (0,0,0) | JOINING PLATE | 16x |
| | OUTER CORNER | 8x |
| | INNER CORNER | 0x |
| | STRETCHER | 0x |
| | | |

TOTAL WEIGHT


(PANELS & HARDWARE)


1815 Lbs


12. LUXURY COUNTER & BAR





















12. LUXURY COUNTER & BAR













ARTFORMS™ PANEL SYSTEM 18


RECESSED WOOD FIRE PIT











IMPORTANT: It is recommended to follow the burner manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Metal liner plate and accessories are not included.

| REQUIRED PANELS | |
|---|----------|
| CLOSED END 18 x 36 PANEL | 4x |
| A OR B 18 x 36 PANEL | 0x |
| CLOSED END 6 x 36 PANEL | 4x |
| CORD 6 x 36 PANEL | 0x |
| IMPORTANT: 18 x 36 panels are so pair/layer or in full pallet only. 6 x 30 are sold per unit or in layer or in fu | 6 panels |

| REQUIRED HARDWARE | | |
|--|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 16x |
| 01:10 | JOINING PLATE | 0x |
| | OUTER CORNER | 8x |
| | INNER CORNER | 0x |
| opopopopopopopopopopopopopopopopopopop | STRETCHER | 0x |
| | | |

TOTAL WEIGHT


(PANELS & HARDWARE)


772 Lbs


14. RECESSED GAS FIRE PIT












IMPORTANT: It is recommended to follow the burner manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan and accessories are not included.



| REQUIRED HARDWARE | | |
|-------------------|-------------------------|------|
| | ANCHOR SLIDE AND NUT | 16x |
| | JOINING PLATE | 0x |
| | OUTER CORNER | 8x |
| | INNER CORNER | 0x |
| rejejejejejejej | STRETCHER | 0x |
| TOTAL WEIG | HT 483 | l he |


(PANELS & HARDWARE)


683 Lbs


15. GAS FIRE PIT












IMPORTANT: It is recommended to follow the firekit manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan and accessories are not included.





| REQUIRED HARDWARE | | |
|-------------------|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 16x |
| 0:0:0 | JOINING PLATE | 0x |
| | OUTER CORNER | 8x |
| S.A. | INNER CORNER | 0x |
| otototototot | STRETCHER | 0x |
| TOTAL WEIG | h 2 h | Lbs |


16. RECESSED RECTANGULAR GAS FIRE PIT














IMPORTANT: It is recommended to follow the firekit manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan and accessories are not included.






RECTANGULAR GAS FIRE PIT









IMPORTANT: It is recommended to follow the firekit manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner plate and accessories are not included.

ightharpoonup1/2" THICK SHIMS







72"


18. SQUARE PLANTER











IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

| REQUIRED PANELS | |
|---|--------|
| CLOSED END 18 x 36 PANEL | 0x |
| A OR B | 4x |
| CLOSED END 6 x 36 PANEL | 4x |
| CORD 6 x 36 PANEL | 0x |
| IMPORTANT: 18 x 36 panels are sol pair/layer or in full pallet only. 6 x 36 are sold per unit or in layer or in ful | panels |

| REQUIRED HARDWARE | | |
|-------------------|-------------------------|------|
| | ANCHOR SLIDE AND NUT | 40x |
| | JOINING PLATE | 8x |
| | OUTER CORNER | 8x |
| | INNER CORNER | 0x |
| riejojojojojoj | STRETCHER | 0x |
| TOTAL WEIG | HT 80% | l he |


(PANELS & HARDWARE)


804 Lbs


19. RECTANGULAR PLANTER











IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

| REQUIRED PANELS | |
|--|-------------|
| CLOSED END 18 x 36 PANEL | 0x |
| A OR B 18 x 36 PANEL | 6x |
| CLOSED END 6 x 36 PANEL | 4x |
| CORD 6 x 36 PANEL | 2x |
| IMPORTANT: 18 x 36 panels are pair/layer or in full pallet only. 6 are sold per unit or in layer or in | x 36 panels |


| REQUIRED HARDWARE | | |
|------------------------|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 56x |
| 61:10 | JOINING PLATE | 14x |
| | OUTER CORNER | 8x |
| D.C. | INNER CORNER | 0x |
| operated at | STRETCHER | 0x |
| TOTAL WEIGHT 1200 I he | | |


(PANELS & HARDWARE)


20. VERTICAL PLANTER











IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.


| REQUIRED PANELS | |
|---|----------|
| CLOSED END 18 x 36 PANEL | 4x |
| A OR B 18 x 36 PANEL | 6x |
| CLOSED END 6 x 36 PANEL | 4x |
| GORD 6 x 36 PANEL | 2x |
| IMPORTANT: 18 x 36 panels are so pair/layer or in full pallet only. 6 x 30 are sold per unit or in layer or in fu | 6 panels |


| REQUIRED HARDWARE | | |
|-------------------|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 62x |
| 2:0:0 | JOINING PLATE | 12x |
| | OUTER CORNER | 18x |
| | INNER CORNER | 0x |
| statestatestati | STRETCHER | 1x |
| TOTAL WEIG | | Lbs |


PRIVACY WALL WITH BENCH














| REQUIRED HARDWARE | | |
|----------------------|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 28x |
| | JOINING PLATE | 2x |
| | OUTER CORNER | 8x |
| | INNER CORNER | 0x |
| ગુનાનાનાનાના | STRETCHER | 2x |
| TOTAL WEIGHT 7/0 Lbs | | |


(PANELS & HARDWARE)


740 Lbs


PRIVACY WALL WITH PLANTER











IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.


| REQUIRED PANELS | |
|---|--------|
| CLOSED END 18 x 36 PANEL | 0x |
| AOR B 18 x 36 PANEL | 6x |
| CLOSED END 6 x 36 PANEL | 4x |
| CORD 6 x 36 PANEL | 2x |
| IMPORTANT: 18 x 36 panels are sol pair/layer or in full pallet only. 6 x 36 are sold per unit or in layer or in ful | panels |


| REQUIRED HARDWARE | | |
|---|-------------------------|-----|
| | ANCHOR SLIDE AND NUT | 43x |
| \$ 10.00 | JOINING PLATE | 24x |
| | OUTER CORNER | 4x |
| | INNER CORNER | 0x |
| determining | STRETCHER | 0x |
| TOTAL WEIGHT (PANELS & HARDWARE) 1206 Lbs | | |


PRIVACY WALL WITH VERTICAL PLANTER













IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.







(PANELS & HARDWARE)


24. RAISED GARDEN











IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.


| REQUIRED PANELS | |
|--|----------|
| CLOSED END 18 x 36 PANEL | 0x |
| A OR B | 10x |
| CLOSED END 6 x 36 PANEL | 4x |
| CORD 6 x 36 PANEL | 6x |
| IMPORTANT: 18 x 36 panels are so pair/layer or in full pallet only. 6 x 3 are sold per unit or in layer or in full parts or in full parts. | 6 panels |


| REQUIRED HARDWARE | | | | |
|--|-------------------------|-----|--|--|
| | ANCHOR SLIDE AND NUT | 54x | | |
| | JOINING PLATE | 18x | | |
| | OUTER CORNER | 8x | | |
| | INNER CORNER | 0x | | |
| -the property of the state of t | STRETCHER | 1x | | |
| TOTAL WEIGHT 1986 Lbs | | | | |


25. CORNER MULTILEVEL RAISED GARDEN












IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.





| REQUIRED HARDWARE | | | | |
|--------------------|-------------------------|-------------|--|--|
| | ANCHOR SLIDE AND NUT | 153x | | |
| 01:10 | JOINING PLATE | 46x | | |
| | OUTER CORNER | 20 x | | |
| | INNER CORNER | 4x | | |
| -V-V-V-V-V-V-V-V-V | STRETCHER | 7x | | |
| TOTAL WEIGI | | 7 Lbs | | |


26. MULTILEVEL RAISED GARDEN













IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.








FIREPLACE WITH BENCH & WOOD PERGOLA













IMPORTANT: Other types of hardware (not included) may be required to make these assemblies (wood screws, concrete anchors, etc.). BELGARD is not responsable for any issue regarding other materials, accessories, other types of hardware, etc. We recommend to consulting an expert/engineer to validate installation of the wood posts of pergola.








L-SHAPE BENCH & VERTICAL PLANTER












REQUIRED PANELS CLOSED END 18 x 36 PANEL **4**x 20x 0x0xIMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.




(PANELS & HARDWARE)


IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

BBQ WITH BENCH & VERTICAL PLANTER










IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.



| REQUIRED HARDWARE | | | | | |
|-------------------|-------------------------|----------------|--|--|--|
| 130x | ANCHOR SLIDE AND NUT | | | | |
| 24x | JOINING PLATE | | | | |
| 40x | OUTER CORNER | | | | |
| 0x | INNER CORNER | | | | |
| 0x | STRETCHER | niojojojojojoj | | | |
| | | | | | |


TOTAL WEIGHT 3921 Lbs


DECITIOED HADDWADE


HIGH TOP GAS FIRE PIT













IMPORTANT: It is recommended to follow the FIREKIT manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan, countertop and accessories are not included.


| REQUIRED PANELS | |
|---|----------|
| CLOSED END 18 x 36 PANEL | 4x |
| A OR B 18 x 36 PANEL | 6x |
| CLOSED END 6 x 36 PANEL | 4x |
| CORD 6 x 36 PANEL | 2x |
| IMPORTANT: 18 x 36 panels are so pair/layer or in full pallet only. 6 x 30 are sold per unit or in layer or in fu | 6 panels |



CORNER BENCH & FIRE PIT








CUT PANEL "B"

18 x 18

CUT PANEL "B"


В

12 x 36



For more details see next page

CUT PANEL "B"



TOTAL WEIGHT

(PANELS & HARDWARE)

IMPORTANT: It is recommended to follow the FIREKIT manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan, countertop and accessories are not included.


36"


Panels "A" can't be replaced by the panels "B".


NOTE: Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers.


CORNER BENCH & FIRE PIT














IMPORTANT: It is recommended to follow the manufacturer's specifications for LED stripes and wire connections. Belgard is not responsible for the conformity of the LED strip inserts.

ARTFORMS™ PANEL SYSTEM

| | | | 1 |
|--|--|--|---|

