



STEP 1 - PLACE REINFORCEMENT
SO LITTLE OR NO OVERLAP
OCCURS IN THE RADIUS AREA. IF
OVERLAP OCCURS, PLACE 2 TO 3
INCHES OF SAND BETWEEN THE
REINFORCEMENT LAYERS.

2"-3" OF SOIL FILL REQUIRED
BETWEEN OVERLAPPED
REINFORCEMENT FOR PROPER
SOIL AND REINFORCEMENT
INTERACTION


↑
PRINCIPLE
REINFORCEMENT
DIRECTION



STEP 2: LAY THE NEXT COURSE
OF BLOCK. MAKE A MARK ON
THE BACK OF THE BLOCKS IN
THE AREAS THAT ARE NOT
REINFORCED. BACKFILL AND
COMPACT THAT COURSE.



STEP 3: PLACE GEOGRID IN THE AREAS WHERE THE MARKS SHOW
GAPS IN THE LOWER REINFORCEMENT PATTERN. CONTINUE NORMAL
WALL CONSTRUCTION, REPEATING THESE STEPS AS NEEDED.



This drawing is for illustrative purposes only and should not be used for construction without the signature of a registered professional engineer.

www.anchordiamond.com

© 2023 ANCHOR Engineering, LLC®
and © 2023 ANCHOR DIAMOND Group. All rights reserved

GeoHold Pro Retaining Wall System

Outside Curves

Scale:

None

Drawn by:

DA

Date:

9/28/2023

Drawing number:

GHP27